



City of Santa Barbara Public Works Department

LATERAL LINER GUIDELINES

To Initiate a Request to Line a Lateral Using Trenchless CIPP Technology

- A written request must be submitted to Dale Escobar, SLIP Coordinator, citing the sewer lateral ID, address, contractor and material proposed to be used.
 - Dale Escobar will review request and provide an approval if acceptable to the City.
 - Response will generally include a copy of the trenchless lateral lining guidelines.
 - Once approved, Contractor may schedule appointment

Scheduling An Appointment

- Lateral lining appointments are on:
 - Monday, Tuesday, Wednesday
 - 8:00 a.m., 10:00 a.m. and 1:00 p.m.
 - Any exception or rescheduling will require prior authorization at least 24 hours in advance.

Installation Process

- Dale Escobar, SLIP Coordinator, or another authorized Wastewater staff person will be on site at the time of installation.
 - No exceptions

Contractor Responsibilities

- Only licensed contractors allowed to work in the Public Right of Way will be allowed to perform lateral lining work.
- The Contractor will be responsible for all traffic control necessary during the course of this job
- Failure to follow the procedures outlined above may result in the Contractor being liable for any damage to the City sewer main or cost recovery for City staff to respond to a spill related the lateral lining work.

Post-Lining and Follow Up

- A post-lining CCTV of the sewer lateral, showing the entire lateral including the wye, is required for submittal to the SLIP Coordinator within 24 hours of installation. Color videos only.
- Liners intruding into a City main will require grinding the protruding portion within 24 hours from insertion date or replacement of the wye.